```
1. Determining dry air mass flow rate:
    la. See code for data from tables
   1b. Saturation Pressure [kPa] (50, 30, 20 g/s):
               3.1417
                        3.2079
                                   3.2463
       in:
                3.1323
                          3.0583
                                   3.0219
       Out:
    lc. Absolute humidity [kg H20/kg Air] (50, 30, 20 g/s):
       in:
               0.0088
                        0.0088
                                   0.0085
       Out:
               0.0200
                          0.0186
                                   0.0181
    ld. Specific volume [m^3/kg] (50, 30, 20 g/s):
               0.0807
                       0.0819
       in:
                                  0.0825
       Out:
               0.0830
                          0.0815
                                   0.0807
       These are all slightly lower than the chart value
   lf. Mass flow rate of dry air [kg/s] (50, 30, 20 g/s):
```

0.1504

0.1489

0.1511

```
See attached code for table enthalpy values.
See attached code for table humidity values.

 Mass flow rates of water vapor [kg/s] (50, 30, 20 g/s):

            0.0013 0.0013
                            0.0013
   at A:
   at B:
            0.0030
                    0.0028
                              0.0027
Enthalpy of Air/vapor mixture [kJ/kg] (50, 30, 20 g/s):
             75.8151 71.8347
       at A:
                                70.4741
       at B:
              75.8151 71.8347
                                  70.4741
       These are all slightly lower than the chart values
```







